

# TYPICAL APPLICATION OF TRAFFIC CONTROL DEVICES FOR A UTILITY WORK ZONE ON A TWO-LANE ROADWAY





Figure 22

# TYPICAL APPLICATION OF TRAFFIC CONTROL DEVICES FOR A UTILITY WORK ZONE ON A TWO-LANE RESIDENTIAL STREET (LOW TRAFFIC VOLUME)




## NOTES:

1. Where flagger is required because of traffic volume or visibility, refer to Figure 22 for set-up.
2. With very few exceptions, this control device set-up is not to be used in rural areas. Typical applications of traffic control devices on other roadways are shown on Figures 21 and 22.

**Figure 23**



**TYPICAL APPLICATION OF  
TRAFFIC CONTROL DEVICES.  
TWO METHODS FOR CONTROLLING PEDESTRIAN TRAFFIC:  
DIRECTING PEDESTRIANS TO  
ANOTHER ROUTE  
OR PROVIDING A WALKWAY**



**NOTES:**

1. Additional advance warning may be necessary.
2. Controls for pedestrians only are shown; vehicular traffic should also be considered.
3. Street lighting should be considered.
4. Use warning lights on barricades.

KEY:  
barricades

**Figure 24**